



Note:
 q = quantity of air flow in cubic feet per minute
 H = Head loss in inches of water gage pressure
 R = Resistance in inches of water gage per $q^2 \times 10^6$

FIGURE 1
 AIRWAY DIAGRAM of BRUCE MINE

No Scale